

Another Country

Assembly instructions
Sleep Series



Sleep Series



Hardware Contents

8x 6mm Allen Screws & washers
4x 5mm Allen Screws (black)
32x 8mm bolts & washers
4x universal connectors & bolts

Tools Required

6mm Allen Key (ideally a longer version with a T-Bar but not essential)
5mm Allen key - standard
8mm Monobloc Spanner or T-Bar Socket Wrench or Magnetic Socket bit for screwdriver or Hex Driver bit for drill
Philips screwdriver

Assembly Instructions

2 persons required.

Bed:

Using the packaging to protect it from being damaged or marked, place the back of the headboard on the floor and fix to the appropriate short end base board (the one with the holes in it) with the 8x long 6mm Allen Keys.

Tighten well and turn the head and base board on its feet. Next, insert two (round) universal connectors into the holes in the base board making sure that the Allen Key screw point is the right way up (i.e. pointing towards you) and that the round holes in the sides of the universal connectors are pointing outwards toward the ends of the base board (i.e. corners). Now get hold of the long base board sides.

Screw the universal connector bolt (large threaded screw) into the metal inserts until fully screwed in (a philips screwdriver might help). Now push the universal connector bolt into the side of the short base board and into the round universal connector. Use the 6mm Allen key hole to turn the threaded screw inward until the ends of the long and short base board meet (whilst you do this, in order to avoid undue leverage being placed on long base board fittings, tilt the headboard forward a little so that the ends of the long base board rest on the floor). Repeat the same fitting procedure for both sides.

Once the long base boards have been connected to the base of the head board, repeat the same procedure with the other short (end-of-bed) base board.

Having assembled the frame, the next item to fix is the middle stretcher. Simply connect this to the middle of the short base boards using the 4x black 5mm Allen screws.

Finally, assemble the 16 slats by screwing in the 8mm bolts using a spanner or socket bit and tighten the headboard screws once more.

Cabinets:

Using the packaging to protect it from being damaged, place the back of the cabinet / night table / blanket chest on the ground and screw in the legs. Without using the legs as a pivot, turn the item on its feet and move into place.

